

W4

	Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Date listed
<b>W4</b>	692	N/A	N/A	101762	N/A	N/A	9-0	14-0	25	32	3" U-Bar (1-1-1-1)	5678.2	No	N/A
	692	N/A	N/A	101781	N/A	N/A	16-0	14-0	24	24.5	3" U-Bar (2-1-2-1)	5678.8	No	N/A
	3203	N/A	N/A	101758	N/A	N/A	9-0	14-0	28	29	2-1/4" U-Bar (varies)	5678.1	No	N/A
	3203	N/A	N/A	101760	N/A	N/A	16-0	14-0	25.5	25.5	3" U-Bar (2-1-1-1)	5678.6	No	N/A
	3200, 3220	240	N/A	101687	102073	N/A	12-2	18-0	25	28	2-1/4" U-Bar (2-1-1-1)	5678.4	YES	N/A
	3200, 3220	240	N/A	101682	102074	N/A	20-2	18-0	25	28	6" C-Channel (1-1-1-1)	5678.9	YES	N/A
	3200, 3220	N/A	N/A	103334	103334	N/A	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.11	YES	N/A
	3602, 3603, 3622	N/A	46X20, 46X17,	102812	N/A	102812	10-2	18-0	25	25.5	None	5678.3	YES	N/A
	525, 525V, 525S, 524, 524V, 524S, 520, 520S	225, 225S, 224, 224S	C5ST, C5SV, C5SS, C4ST, C4SV, C4SS, C0ST, C0SS	101856	101856	101856	12-2	18-0	25	25	3" U-Bar (2-1-2-1)	5678.5	YES	N/A
	524, 524V, 524S, 520, 524, 524V, 524S, 520,	224, 224S	C4ST, C4SV, C4SS, C4ST, C4SV, C4SS,	101886	101886	101886	16-2	18-0	25	25	4" C-Channel (1-1-1-1)	5678.7	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102126	102126	102126	20-2	18-0	25	25	6" C-Channel (1-1-1-1)	5678.10	YES	N/A
	524, 524V, 524S, 520, 520S	N/A	C4ST, C4SV, C4SS, C0ST, C0SS	103333	103333	103333	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.12	YES	N/A
	902	N/A	C2AL	103332	103332	103332	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.13	YES	N/A

W5

W5	Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
	902	N/A	C2AL	103275	N/A	103275	12-2	18-0	32	32	2"x2" Alum. Angle (2-1-1-1)	5678.17	YES	N/A
	902	N/A	C2AL	103294	N/A	103294	16-2	18-0	32	32	4" C-Channel (1-1-1-1)	5678.22	YES	N/A
	902	N/A	C2AL	103295	N/A	103295	16-2	18-0	30	30	2"x2" Alum. Angle (2-1-1-1)*	5678.21	No	N/A
	902	N/A	C2AL	103296	N/A	103296	20-2	18-0	30	30	6" C-Channel (1-1-1-1)	5678.23	YES	N/A
	902	N/A	C2AL	103324	N/A	103324	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.26	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, COST, COSS	101874	101874	101874	8-2	18-0	30	30	2-1/4" U-Bar (1-1-1-1)	5678.14	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, COST, COSS	101875	101875	101875	10-2	18-0	30	30	3" U-Bar (1-1-1-1)	5678.15	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, COST, COSS	101869	101869	101869	12-2	18-0	30	30	3" U-Bar (2-2-2-2)	5678.16	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, COST, COSS	101885	101885	101885	16-2	18-0	32	32	4" C-Channel (1-1-1-1)	5678.20	YES	N/A
524, 524V, 524S, 520, 520S	N/A	C4ST, C4SV, C4SS, COST, COSS	103319	N/A	103319	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.25	YES	N/A	
3200, 3220	240	N/A	200040	102079	N/A	16-2	18-0	30	32	3" U-Bar (2-2-2-2)	5678.19	YES	N/A	
3200, 3220	N/A	N/A	103320	N/A	N/A	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.24	YES	N/A	
3602, 3603, 3622	N/A	56X20, 56X17,	102891	N/A	102891	14-2	18-0	30	34	3" U-Bar (2-1-1-1)	5678.18	YES	N/A	

\* - 2"x2" aluminum angle is offset with 4"x6" plates

W6

	Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
<b>W6</b>	3200, 3220	240	N/A	101617	102082	N/A	10-2	18-0	37	40	3" U-Bar (2-1-1-1)	5678.27	YES	N/A
	3200, 3220	240	N/A	101678	102083	N/A	12-2	18-0	40	40	3" U-Bar (2-1-2-1)	5678.30	YES	N/A
	3602, 3603, 3622	N/A	66X20, 66X17,	102813	N/A	102813	10-2	18-0	37	37	3" U-Bar (2-1-1-1)	5678.28	YES	N/A
	3602, 3603, 3622	N/A	66X20, 66X17,	102890	N/A	102890	14-2	18-0	37	42	3" U-Bar (2-2-2-2)	5678.32	YES	N/A
	902	N/A	C2AL	103324	N/A	103324	22-2	18-0	33	34	6" C-Channel (1-1-1-1) and 3" U-Bar (2-2-2-2) and 2x2 AL Angle (1-1-1-0)	6218.21	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102445	102445	102445	10-2	18-0	37	42	3" U-Bar (2-1-2-1)	5678.29	YES	N/A
	524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102446	102446	102446	12-2	18-0	37	42	3" U-Bar (2-2-2-2)	5678.31	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102585	102585	102585	14-2	18-0	37	38	4" C-Channel (1-1-1-1)	5678.33	YES	N/A	

W8

	Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
<b>W8</b>	3200, 3220	240	N/A	101705	102085	N/A	12-2	18-0	52	58	4" C-Channel (1-1-1-1)	5684.7	YES	YES
	524, 520	224	C4ST, C0ST	102645	102645	102645	12-2	18-0	50	56	4" C-Channel (1-1-1-1)	5684.8	YES	YES
	524, 520	224	C4ST, C0ST	103288	103288	103288	14-2	18-0	50	56	4" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5684.9	YES	YES