

# W1 DOOR LIST

Cloday Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Cloday Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
3150	210	N/A	102964	102964	N/A	10-2	18-0	13.5	13.5	None	N/A	No	N/A
3150	210	N/A	102965	102965	N/A	12-2	18-0	13.5	13.5	2-1/4" U-Bar (1-0-1-0)	N/A	No	N/A
3150	210	N/A	102966	102966	N/A	14-2	18-0	13.5	13.5	2-1/4" U-Bar (1-1-1-1)	N/A	No	N/A
3200, 3220, 3300	240	N/A	102887	102887	N/A	10-2	18-0	20	21	None	N/A	No	N/A
3200, 3220	240	N/A	102881	102881	N/A	12-2	18-0	13.5	13.5	None	N/A	No	N/A
3200, 3220	240	N/A	102883	102883	N/A	14-2	18-0	13.5	13.5	3" U-Bar (1-0-1-0)	N/A	No	N/A
3200, 3220	240	N/A	103611	103611	N/A	16-2	18-0	13.5	13.5	2-1/4" U-Bar (1-0-1-0)	N/A	No	N/A
3200, 3220	240	N/A	103619	103619	N/A	20-2	18-0	13.5	13.5	3" U-Bar (2-1-1-1)	N/A	No	N/A
3300	N/A	N/A	102888	N/A	N/A	12-2	18-0	13.5	13.5	None	N/A	No	N/A
3300	N/A	N/A	102889	N/A	N/A	14-2	18-0	13.5	13.5	3" U-Bar (1-0-1-0)	N/A	No	N/A
3717, 3718, 3720, 3722	N/A	N/A	104091	N/A	N/A	12-2	18-0	13.5	13.5	None	N/A	No	N/A
3717, 3718, 3720, 3722	N/A	N/A	104092	N/A	N/A	14-2	18-0	13.5	13.5	3" U-Bar (1-0-1-0)	N/A	No	N/A
3717, 3718, 3720, 3722	N/A	N/A	104083	N/A	N/A	16-2	18-0	13.5	13.5	3" U-Bar (1-1-1-1)	N/A	No	N/A
3717, 3718, 3720, 3722	N/A	N/A	104094	N/A	N/A	20-2	18-0	13.5	13.5	3" U-Bar (2-1-1-1)	N/A	No	N/A
520, 520S	N/A	N/A	102967	N/A	N/A	10-2	18-0	16.5	16.5	None	N/A	No	N/A
524, 524S, 524V, 525, 525S, 525V	224, 224S, 225, 225S	N/A	102961	102961	N/A	10-2	18-0	13.5	13.5	2-1/4" 24Ga U-Bar (1-0-1-0)	N/A	No	N/A
524, 524S, 524V, 525, 525S, 525V	224, 224S, 225, 225S	N/A	102963	102963	N/A	14-2	18-0	13.5	13.5	3" U-Bar (1-1-1-1)	N/A	No	N/A
524, 524S, 524V, 520, 520S	224, 224S	N/A	103056	103056	N/A	16-2	18-0	13.5	13.5	3" U-Bar (2-1-1-1)	N/A	No	N/A
524, 524S, 524V, 520, 520S	224, 224S	N/A	103618	103618	N/A	20-2	18-0	13.5	13.5	3" U-Bar (2-2-2-2)	N/A	No	N/A
902	N/A	N/A	103291	N/A	N/A	12-2	18-0	16.5	16.5	None	N/A	No	N/A
902	N/A	N/A	103292	N/A	N/A	14-2	18-0	13.5	13.5	None	N/A	No	N/A
902	N/A	N/A	103610	N/A	N/A	16-2	18-0	13.5	13.5	Stock 1-1/4"x1-1/4" L-angles (1-1-1-1)	N/A	No	N/A
902	N/A	N/A	103617	N/A	N/A	20-2	18-0	13.5	13.5	Stock 2"x2" L-angles (1-1-1-1) & 3" U-Bar (2-1-1-1)	N/A	No	N/A
692, 652V	N/A	N/A	102894	N/A	N/A	9-0	14-0	13	15	2-1/4" U-Bar (1-1-0-1)	N/A	No	N/A
692, 652V	N/A	N/A	102895	N/A	N/A	16-0	14-0	12.5	14	3" U-Bar (2-1-1-1)	N/A	No	N/A
692, 652V	N/A	N/A	102899	N/A	N/A	18-0	14-0	12.5	14	3" U-Bar (2-1-2-1)	N/A	No	N/A
3154, 3155	230B	N/A	102981	102981	N/A	9-0	14-0	13	15	2-1/4" U-Bar (1-0-1-0)	N/A	No	N/A
3154, 3155	230B	N/A	102982	102982	N/A	16-0	14-0	12.5	14	2-1/4" U-Bar (2-1-2-1)	N/A	No	N/A
3154, 3155	230B	N/A	102983	102983	N/A	18-0	14-0	12.5	14	3" U-Bar (2-1-1-1)	N/A	No	N/A
3201, 3203	250	N/A	102884	102884	N/A	9-0	14-0	13	15	None	N/A	No	N/A
3201, 3203	250	N/A	102885	102885	N/A	16-0	14-0	12.5	14	2-1/4" U-Bar (1-0-1-0)	N/A	No	N/A
3201, 3203	250	N/A	102886	102886	N/A	18-0	14-0	12.5	14	3" U-Bar (1-1-1-1)	N/A	No	N/A

## W4 DOOR LIST

Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Date listed
692	N/A	N/A	101762	N/A	N/A	9-0	14-0	25	32	3" U-Bar (1-1-1-1)	5678.3	No	N/A
692	N/A	N/A	101781	N/A	N/A	16-0	14-0	24	24.5	3" U-Bar (2-1-2-1)	5678.4	No	N/A
3203	N/A	N/A	101758	N/A	N/A	9-0	14-0	28	29	2-1/4" U-Bar (varies)	5678.1	No	N/A
3203	N/A	N/A	101760	N/A	N/A	16-0	14-0	25.5	25.5	3" U-Bar (2-1-1-1)	5678.2	No	N/A
3200, 3220	240	N/A	101687	102073	N/A	12-2	18-0	25	28	2-1/4" U-Bar (2-1-1-1)	5678.5	YES	N/A
3200, 3220	240	N/A	101682	102074	N/A	20-2	18-0	25	28	6" C-Channel (1-1-1-1)	5678.6	YES	N/A
3200, 3220	N/A	N/A	103334	103334	N/A	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.7	YES	N/A
3717, 3718, 3720, 3722	240U	C7X17, C7X18, C7X20, C0X22	104040	104040	104040	10-2	18-0	25	25	2-1/4" U-Bar (1-0-1-0)	5678.8	No	N/A
525, 525V, 525S, 524, 524V, 524S, 520, 520S	225, 225S, 224, 224S	C5ST, C5SV, C5SS, C4ST, C4SV, C4SS, C0ST, C0SS	101856	101856	101856	12-2	18-0	25	25	3" U-Bar (2-1-2-1)	5678.9	YES	N/A
524, 524V, 524S, 520, 224, 224S	224, 224S	C4ST, C4SV, C4SS, C4ST, C4SV, C4SS,	101886	101886	101886	16-2	18-0	25	25	4" C-Channel (1-1-1-1)	5678.10	YES	N/A
524, 524V, 524S, 520, 224, 224S	224, 224S	C4ST, C4SV, C4SS,	102126	102126	102126	20-2	18-0	25	25	6" C-Channel (1-1-1-1)	5678.11	YES	N/A
524, 524V, 524S, 520, 520S	N/A	C4ST, C4SV, C4SS, C0ST, C0SS	103333	103333	103333	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.12	YES	N/A
902	N/A	C2AL	103332	103332	103332	24-2	18-0	25	25	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.13	YES	N/A

## W5 DOOR LIST

Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Date listed
902	N/A	C2AL	103275	N/A	103275	12-2	18-0	32	32	2"x2" Alum. Angle (2-1-1-1)	5678.22	YES	N/A
902	N/A	C2AL	103294	N/A	103294	16-2	18-0	32	32	4" C-Channel (1-1-1-1)	5678.23	YES	N/A
902	N/A	C2AL	103295	N/A	103295	16-2	18-0	30	30	2"x2" Alum. Angle (2-1-1-1)*	5678.24	No	N/A
902	N/A	C2AL	103296	N/A	103296	20-2	18-0	30	30	6" C-Channel (1-1-1-1)	5678.25	YES	N/A
902	N/A	C2AL	103324	N/A	103324	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.26	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	101874	101874	101874	8-2	18-0	30	30	2-1/4" U-Bar (1-1-1-1)	5678.17	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	101875	101875	101875	10-2	18-0	30	30	3" U-Bar (1-1-1-1)	5678.18	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	101869	101869	101869	12-2	18-0	30	30	3" U-Bar (2-2-2-2)	5678.19	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	101885	101885	101885	16-2	18-0	32	32	4" C-Channel (1-1-1-1)	5678.20	YES	N/A
524, 524V, 524S, 520, 520S	N/A	C4ST, C4SV, C4SS, C0ST, C0SS	103319	103319	103319	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.22	YES	N/A
3200, 3220	240	N/A	200040	102079	N/A	16-2	18-0	30	32	3" U-Bar (2-2-2-2)	5678.14	YES	N/A
3200, 3220	N/A	N/A	103320	103320	N/A	22-2	18-0	30	30	6" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5678.15	YES	N/A
3717, 3718, 3720, 3722	240U	C7X17, C7X18, C7X20, C0X22	104044	104044	104044	14-2	18-0	30	34	3" U-Bar (2-1-2-1)	5678.16	No	N/A

\* - 2"x2" aluminum angle is offset with 4"x6" plates

## W6 DOOR LIST

Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
3200, 3220	240	N/A	101617	102082	N/A	10-2	18-0	37	40	3" U-Bar (2-1-1-1)	5678.27	YES	N/A
3200, 3220	240	N/A	101678	102083	N/A	12-2	18-0	40	40	3" U-Bar (2-1-2-1)	5678.28	YES	N/A
3717, 3718, 3720, 3722	240U	C7X17, C7X18, C7X20, C0X22	104039	104039	104039	10-2	18-0	37	37	3" U-Bar (2-1-1-1)	5678.29	No	N/A
3717, 3718, 3720, 3722	240U	C7X17, C7X18, C7X20, C0X22	104043	104043	104043	14-2	18-0	37	42	3" U-Bar (2-2-2-2)	5678.30	No	N/A
902	N/A	C2AL	103324	N/A	103324	22-2	18-0	33	34	6" C-Channel (1-1-1-1) and 3" U-Bar (2-2-2-2) and 2x2 AL Angle (1-1-1-0)	5678.34	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102445	102445	102445	10-2	18-0	37	42	3" U-Bar (2-1-2-1)	5678.31	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102446	102446	102446	12-2	18-0	37	42	3" U-Bar (2-2-2-2)	5678.32	YES	N/A
524, 524V, 524S, 520, 520S	224, 224S	C4ST, C4SV, C4SS, C0ST, C0SS	102585	102585	102585	14-2	18-0	37	38	4" C-Channel (1-1-1-1)	5678.33	YES	N/A

## W8 DOOR LIST (all w8 doors are impact-resistant)

Clopay Model Numbers	Holmes Model Numbers	Ideal Model Numbers	Clopay Drawing Number	Holmes Drawing Number	Ideal Drawing Number	Door Width (Max) Ft-In	Door Height (Max) Ft-In	Design Load Positive (PSF)	Design Load Negative (PSF)	Horizontal Reinforcement	Florida Approval Seq. No.	TDI listed	Dade listed
3200, 3220	240	N/A	101705	101705	N/A	12-2	18-0	52	58	4" C-Channel (1-1-1-1)	5684.10	YES	YES
524, 520	224	C4ST, C0ST	102645	102645	102645	12-2	18-0	50	56	4" C-Channel (1-1-1-1)	5684.11	YES	YES
524, 520	224	C4ST, C0ST	103288	103288	103288	14-2	18-0	50	56	4" C-Channel (1-1-1-1) and 3" U-Bar (1-1-1-1)	5684.12	YES	YES